




For installation of Taurus spike wall light.
Model. UTU-30821-30826.

Product drawing (dimensions)


SUITABLE FOR WET LOCATIONS




MOUNTING DETAIL



NOTE
Mounts over
a 3"Octagonal
Junction box.




1



2


Center the Back Plate over
the J Box and Secure the
back plate to the wall




3

Ensure watertight seal using UL
approved silicone based sealant.


Connect Power and
Ground Wire.




4




5



6



7



8

Notice to installer :

- 1.WIRING INSTRUCTIONS Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.**
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,Check that the supply voltage is the same as the installed ballast voltage.**

Ligman Lighting USA

7144 NW Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com

UTU-30821/15/07/14/REV.1

1/1



FM-TS-13/25-05-2007-REV.2