


INSTALLATION AND SERVICE MANUAL



For installation of Jet 16,19 cylindrical and square wall down light.
Model. UJE-30453-30454 and UJE-30703-30704.

Product drawing (dimensions)


SUITABLE FOR WET LOCATIONS



UJE-30453-UJE-30454


UJE-30703-UJE-30704

MOUNTING DETAIL




TOOL

1




NOTE
Mounts over a 3"
Octagonal Junction box.

2




3

Using the nylon washers and
the 7mm. nut driver secure
the back plate to the wall




Ensure watertight seal using UL
approved silicone based sealant.

4



Connect Power and
Ground Wire.

5



Notice to installer :

- 1.WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,Check that the supply voltage is the same as the installed ballast voltage.**

Ligman Lighting USA

7144 NW Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com


UJE-30453/04/07/14/REV.1

1/2




FM-TS-13/25-05-2007-REV.2


6




7




8




9



10



11



12

