



INSTALLATION AND SERVICE MANUAL




For installation of Tango 6, 16 cylindrical and square surface downlight dia 7.32" LED
Model. UTA-80421 and UTA-80431.



Product drawing (dimensions) SUITABLE FOR WET LOCATIONS





UTA-80421



MOUNTING DETAIL




UTA-80431




MOUNTING DETAIL

1




NOTE Mounts over a 3" or 4" Octagonal Junction box.

2




Attach Galvanized back plate to J Box.

3




4




Using provided and the 0.25" nut driver secure the back plate to the wall

5




Ensure watertight seal using UL approved silicone based sealant.

6




Connect Power and Ground Wire.

7



8



Notice to installer :

- 1.WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,Check that the supply voltage is the same as the installed ballast voltage.**

Ligman Lighting USA

7144 NW Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com

UTA-80421 05/09/14 REV.1

1/1



FM-TS-13/25-05-2007-REV.2