


INSTALLATION AND SERVICE MANUAL




For installation of Jet cylindrical and square wall down light COB.
Model. UJE-30391 and UJE-30411.

Product drawing (dimensions)


SUITABLE FOR WET LOCATIONS




UJE-30391



UJE-30411




MOUNTING DETAIL




TOOL

NOTE


Mounts over
a 3" Octagonal
Junction box.



①




②




③

Using the nylon washers
and the 7mm. nut driver
secure the back
plate to the wall

④




Ensure watertight seal using UL
approved silicone based sealant.



⑤

Connect Power
and Ground Wire.



⑥

Notice to installer :

- 1.WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,Check that the supply voltage is the same as the installed ballast voltage.**

Ligman Lighting USA

7144 NW Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com

UJE-30391 17/03/16/REV.0
1/1

ISO 9001
ISO 14001
BUREAU VERITAS
Certification



FM-TS-13/25-05-2007-REV.2