

INSTALLATION AND SERVICE MANUAL



For installation of Cinati wall washer LED.
Model. UCI-30121 and UCI-30131.

<p>Product drawing (dimensions)</p> <p>UCI -30121</p> <p>UCI-30131 (LENS TYPE)</p>	<p>SUITABLE FOR WET LOCATIONS</p> <p>MOUNTING DETAIL</p> <p>TOOL</p>	<p>NOTE Mounts over a Junction box.</p> <p>①</p>
-------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------	-------------------------------------------------------------

②

Position the Back Plate over the J Box and Secure the back plate to the wall

③

④

Ensure watertight seal using UL approved silicone based sealant.

⑤

Connect Power and Ground Wire.

⑥

⑦

Notice to installer :

- 1.WIRING INSTRUCTIONS Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.**
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,Check that the supply voltage Is the same as the Installed ballast voltage.**

Ligman Lighting USA

7144 NE Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100