



For Installation of Jet Surface Exterior Downlights.  
Model. UJE-80052,UJE-80062


**Product drawing (dimensions) SUITABLE FOR WET LOCATIONS**




1




2




3




4




5



6



7



**Notice to installer :**

- 1.WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,Check that the supply voltage is the same as the installed ballast voltage.**

**Ligman Lighting USA**

7144 NE Progress Court, Hillsboro  
Oregon, 97124, USA  
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com

UJE-80052 30/05/20 /REV.0 /RON.  
1/1

FM-TS-13-2/15-03-2018/Rev.3