


# INSTALLATION AND SERVICE MANUAL





For installation of Mic medium floodlight symmetrical luminaire LED RGBW.  
Model. MI-50384.








Product drawing (dimensions)



SUITABLE FOR WET LOCATIONS



MOUNTING DETAIL



## Notice to installer :

1. **WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
2. This fixture has a **VOLTAGE SPECIFIC BALLAST**, Check that the supply voltage is the same as the installed ballast voltage.

Ligman Lighting USA

Tanasbourne Commerce Center  
3302 Nw 211th Terrace  
Hillsboro Oregon 97124  
Tel : 503-645-0500, Fax : 503-645-8100

www.ligmanlightingusa.com

UMI-50384/24/11/16/REV.0  
1/1



FM-TS-13/25-05-2007-REV.2

## DMX SYSTEM BLOCK DIAGRAM

