

# INSTALLATION AND SERVICE MANUAL






For installation of Sandy semi-recessed wall light.


Model. USA-40125-26, USA-40135-36, USA-40143-44, USA-40153-54, USA-40165-66, USA-40175-76.

Product drawing (dimensions)


SUITABLE FOR WET LOCATIONS




1




2




3




4




5



6



7



## Notice to installer :

- 1.WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,Check that the supply voltage is the same as the installed ballast voltage.**

Ligman Lighting USA

7144 NW Progress Court, Hillsboro  
Oregon, 97124, USA  
Tel : 503 645 0500 | Fax : 503 645 8100

[www.ligmanlightingusa.com](http://www.ligmanlightingusa.com)

USA-40125 03/09/14 REV.1  
1/1



FM-TS-13/25-05-2007-REV.2