


INSTALLATION AND SERVICE MANUAL



For installation of Taurus 2 Bollard Dia.7.3" LED Clear Diffuser
Model. UTU-10157-SB-K4, UTU-10167-SB-K4



Notice to installer :

- 1. WIRING INSTRUCTIONS Warning :** RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2. This fixture has a VOLTAGE SPECIFIC BALLAST, Check that the supply voltage is the same as the installed ballast voltage.**

Ligman Lighting USA

7144 NE Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com

UTU-10157-SB-K4 30/08/2024 REV.0

FM-TS-13-1/13-05-2563/Rev.6