



INSTALLATION AND SERVICE MANUAL

For Installation of Odessa18 surface exterior downlight RGBW.
Model. UOD-80032,UOD-80034.


Product drawing (dimensions)



WIRING DIAGRAM LUMINAIRES



WARNING
Switch off mains power supply
before joining the connectors



Notice to installer :

1.WIRING INSTRUCTIONS Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.

2.This fixture has a VOLTAGE SPECIFIC BALLAST,Check that the supply voltage is the same as the installed ballast voltage.

Ligman Lighting USA


7144 NE Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100

DMX WIRING DIAGRAM



GREEN	GROUND
BLACK	120/277 HOT
WHITE	NEUTRAL
YELLOW	DMX GROUND
PURPLE	DMX +
GREY	DMX -

SINGLE FIXTURE CONNECTION



FOR LOOPING TO MULTIPLE FIXTURES

