


INSTALLATION AND SERVICE MANUAL





For installation of Martini small LED wall area light luminaire type II, III, IV.
Model. UMN-31671-31672, UMN-31681-31682, UMN-31691-31692.

Product drawing (dimensions)





SUITABLE FOR WET LOCATIONS




NOTE

Mounts over
a 3"Octagonal
Junction box.


1




2



3



4



5

Connect power and ground wire

Notice to installer :

- 1.WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,Check that the supply voltage is the same as the installed ballast voltage.**

Ligman Lighting USA

7144 NW Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com

UMN-31671/02/09/14/REV.0
1/2

ISO 9001
ISO 14001
BUREAU VERITAS
Certification



FM-TS-13/25-05-2007-REV.2

