





# INSTALLATION AND SERVICE MANUAL

For installation of Martini Area lighting luminaire

## Product drawing

IP54 IK07




NOTE: For multiple Martini heads, please follow the same procedure as shown on this installation sheet.


These fixtures are pre-wired and it is not necessary to access the lamp and driver enclosure.

Remove tenon adapter top exposing wiring chamber.

1




2




Feed factory provided wires through the arm and secure the fixture onto the tenon adapter top with stainless steel screws provided on the top and bottom of the arm.

3




4



Replace tenon adapter top and secure with set screws provided

5



Install fixture on top of the tenon and tighten using set screws provided

## Notice to installer :

**1.WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.

**2.This fixture has a VOLTAGE SPECIFIC BALLAST,Check that the supply voltage is the same as the installed ballast voltage.**

Ligman Lighting USA

7144 NW Progress Court, Hillsboro  
Oregon, 97124, USA  
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com



ISO 9001  
ISO 14001  
BUREAU VERITAS  
Certification



FM-TS-13/25-05-2007-REV.2