


INSTALLATION AND SERVICE MANUAL




For installation of Tango 5, 15 cylindrical and square surfac downlight dia 6.3" LED
Model. UTA-80401 and UTA-80411.

Product drawing (dimensions) SUITABLE FOR WET LOCATIONS




UTA-80401

MOUNTING DETAIL




UTA-80411

MOUNTING DETAIL




TOOL



1




NOTE Mounts over a 3" or 4" Octagonal Junction box.




Attach Galvanized back plate to J Box.





Using provided and the 0.25" nut driver secure the back plate to the wall



Ensure watertight seal using UL approved silicone based sealant.



Connect Power and Ground Wire.



Notice to installer :

- 1.WIRING INSTRUCTIONS** Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,Check that the supply voltage is the same as the installed ballast voltage.**

Ligman Lighting USA

7144 NW Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500 | Fax : 503 645 8100

www.ligmanlightingusa.com

UTA-80401 05/09/14/REV.1

1/1



FM-TS-13/25-05-2007-REV.2