


INSTALLATION AND SERVICE MANUAL

For Installation of Melbourne 7 inground uplight + Accessories A614491.
Model. UMEL-60061 and UMEL-60063


Product drawing (dimensions)

SUITABLE FOR WET LOCATIONS




Static load resistance 5000 kg


OK
YES




NO




NO



①




②



③

Accessories A614491 :
Glass suction cup















Notice to installer :

1.WIRING INSTRUCTIONS Warning : RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.

Ligman Lighting USA

7144 NE Progress Court, Hillsboro
Oregon, 97124, USA
Tel : 503 645 0500



Note : Brush finish stainless steel products requirement to wipe the product periodically with a light oil (WD40 or equivalent) to remove any staining.