



INSTALLATION AND SERVICE MANUAL





For installation of Gandalf 26 Floodlight LED.
Model. UGA-51088, AND UGA-51089.







Product drawing (dimensions)



SUITABLE FOR WET LOCATIONS



MOUNTING DETAIL



Notice to installer :

- 1.WIRING INSTRUCTIONS Warning :** RISK OF FIRE AND ELECTRICAL SHOCK. : FIXTURE MUST BE INSTALLED BY A QUALIFIED ELECTRICIAN ONLY>FIXTURE IS INTENDED FOR INSTALLATION IN ACCORDANCE WITH THE NATIONAL ELECTRICAL CODE, LOCAL AND FEDERAL CODE SPECIFICATIONS. DISCONNECT POWER BEFORE SERVICING.
- 2.This fixture has a VOLTAGE SPECIFIC BALLAST,**Check that the supply voltage is the same as the installed ballast voltage.

Ligman Lighting USA

Tanasbourne Commerce Center
3302 Nw 211th Terrace
Hillsboro Oregon 97124
Tel : 503-645-0500, Fax : 503-645-8100
www.ligmanlightingusa.com

UGA-51088 24/11/16/REV.0
1/2



FM-TS-13/25-05-2007-REV.2

